30M Infrared Internet Camera

ICA-310

User's Manual

Version: 3.00

Date: April. 2009

Copyright

Copyright © 2009 by PLANET Technology Corp. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of PLANET.
PLANET makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not PLANET, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, PLANET reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

FCC Caution

To assure continued compliance. (example-use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the Following two conditions: (1) This device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm (8 inches) during normal operation.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

WEEE Regulation

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Revision

User's Manual for PLANET 30M Infrared Internet Camera
Model: ICA-310
Rev: 3.0 (April, 2009)
Part No. EM-ICA310v3

Table of Content

1. Introduction 5
   - 1.1 Overview 5
   - 1.2 Features 5
   - 1.3 Package Contents 6
2. Basic Setup 7
   - 2.1 System Requirements 7
   - 2.2 Physical Details 8
   - 2.3 Hardware Installation 9
   - 2.4 Initial Utility Installation 9
   - 2.5 IP Wizard 12
   - 2.6 Configure With IP Wizard 14
   - 2.7 UPnP Function 17
     - 2.7.1 Windows XP 17
     - 2.7.2 Windows Vista 21
   - 2.8 Setup ActiveX to use the ICA-310 23
     - 2.8.1 Internet Explorer 6 for Windows XP 23
     - 2.8.2 Internet Explorer 7 for Windows XP 24
     - 2.8.3 Internet Explorer 7 for Windows Vista 25
3. Web-based Management 26
   - 3.1 Introduction 26
   - 3.2 Connecting to ICA-310 26
   - 3.3 Live View 28
   - 3.4 ActiveX Control 31
     - 3.4.1 Digital Zoom 32
     - 3.4.2 Record 32
     - 3.4.3 Snapshot 33
     - 3.4.4 Statistics 33
     - 3.4.5 About 34
   - 3.5 Network 35
     - 3.5.1 Network 35
     - 3.5.2 DDNS server 36
     - 3.5.3 PPPoE 37
     - 3.5.4 Streaming 39
     - 3.5.5 UPnP 40
     - 3.5.6 IP Filter 41
     - 3.5.7 IP Notification 42
   - 3.6 Camera 44
     - 3.6.1 Picture 44
     - 3.6.2 PTZ Setting 45
     - 3.6.3 Preset Setting 46
     - 3.6.4 Tour Setting 46
   - 3.7 System 48
     - 3.7.1 System 48
     - 3.7.2 Date & Time 49
     - 3.7.3 Maintenance 50

3.8 Video 52
3.8.1 Common 52
3.8.2 MPEG4/VGA 53
3.8.3 MPEG4/QVGA 54
3.8.4 MPEG4/QQVGA 55
3.8.5 VIDEO/JPEG 56
3.9 User 57
3.10 E-Mail 58
3.11 Object Detection 59
3.12 Event Server 60
3.12.1 FTP Server 60
3.12.2 TCP Server 61
3.12.3 HTTP Server 62
3.13 Event Schedule 63
3.13.1 Setting 63
3.13.2 Record 64
Appendix A: Reset Factory Default Settings 65
Appendix B: PING IP Address 66
Appendix C: Bandwidth and Video Size Estimation 67
Appendix D: DDNS Application 69

1. Introduction

This 30M Infrared Internet Camera is an inexpensive fully scalable surveillance technology. Because the 30M Infrared Internet Cameras can be plugged into your existing local area network infrastructure, you will potentially save thousands of dollars on unnecessary cabling.

The 30M Infrared Internet Camera is accessible via the LAN or Internet connection. Connect your 30M Infrared Internet Camera directly to a local area network or xDSL modem, and with Microsoft Internet Explorer you get instant, on demand video streams. Within minutes you can set up the 30M Infrared Internet Camera to capture a video sequence to a PC. The live video image can be uploaded to a website for the world to see or made available only to select users on the network.

Compliant with IEEE802.3af PoE standard, it can easily to obtain power source when it is locate to a place that is no power outlet.

1.1 Overview

This user's manual explains how to operate the 30M Infrared Internet Camera from a computer. Basically, the user's manual is written to be read on the computer display. However, users might consider printing it out to access easily and read it before you operate the Network Camera.

1.2 Features

- AXIS compatible SDK
- high quality 1/3 inch color CCD sensor of 30M IR distance
- Clear and high-image quality pictures in the daytime and at night
- 3GGP for 3G mobile remote application
- Compliant with IEEE 802.3af (PoE)
- Multi-profile encoder supports MPEG-4 and M-JPEG video compression simultaneously
- IR LED used on ICA-310 are 4 times brighter than ordinary IR LED
- Special mental base enhances lighting and dissipates heat
- Weather-proof protection housing against the various weather
- Plug-N-Watch is able to simplify system integration in an existing network environment
- Supporting TCP/IP networking, SMTP e-mail, and HTTP public network standards, ICA-310 can be applied and utilized to a mixed IP network environment
- Easy configuration: the network administrator can configure and manage ICA-310 via Windows-based utility or web interface
- DDNS, PPPoE, FTP upload supports provide more alternative in your surveillance network
- Motion Detection, the motion detection feature can monitor any suspicious movement in specific area

1.3 Package Contents

User can find the following items in the package for ICA-310:

1. ICA-310 x 1
2. Power adapter x 1
3. Wall mount accessories x 1
4. User's Manual and Utility CD x 1
5. Quick Installation Guide x 1

NOTE :

1. If any of the above items are missing, please contact your dealer immediately.
2. Using the power supply that is not the one included in ICA-310 packet will cause damage and void the warranty for this product.
3. If ICA-310 is obtaining power from a PoE device, you don't have to connect the power adapter.

2. Basic Setup

This chapter provides details of installing and configuring the ICA-310

2.1 System Requirements

Network Interface	10/100MBase-TX Ethernet
Monitoring System	Recommended for Internet Explorer 6.0 or later
Basic System Hardware	· CPU: Pentium 4, 3.0GHz or above · Memory Size : 512 MB (512 MB or above Recommended) · VGA card resolution : 1024 x 768 or above · VGA card memory : 64 MB or above · Sound card: Necessary **· Network bandwidth: In VGA resolution mode, minimum upload bandwidth is 1Mbps.**

NOTE: The listed information is minimum system requirements only. Actual requirement will vary depending on the nature of your environment.

2.2 Physical Details

Identification of ICA-310 cables



RS-485 (Blue: D+ / Red: D-):
Connect to a Pan/Tilt external scanner unit.

This connector is built inside the ICA-310 housing. If you need to install the RS-485, please contact your dealer for more information.

NOTE: The RS-485 of ICA-310 is master that can control external scanner.

Power Connector:
The input power is 12VDC.

NOTE: Supplies the power to the ICA-310 with the power adapter included in package.

Video Output Connector (BNC port):

The ICA-310 also provides composite video output. User can use BNC video cable to connect the ICA-310 with a TV monitor or DVR.

RJ-45 LAN Connector:
For connect a LAN cable to your Hub/Switch or PoE device.

The LAN port is a RJ-45 connector for connections to 10Base-T Ethernet or 100Base-TX Fast Ethernet cabling. This Ethernet port built N-Way protocol can detect or negotiate the transmission speed of the network automatically. Please use Category 5 “straight” cable to connect the ICA-310 to a 100Mbps Fast Ethernet network switch or hub. If you are plan to connect the ICA-310 to a PoE device (such as PoE switch) to get the power source, you will also connect the RJ-45 cable from this connector to the PoE device.

NOTE: In case you need to connect the device to PC or notebook directly, you should use a cross-over cable instead.
Use only one power source, either 12VDC or Power over Ethernet through UTP cable at one time. Use of both powers will damage the camera permanently.

2.3 Hardware Installation

1. Fix ICA-310 to the location with wall mount fixture.
2. Plug-in Ethernet Cable into RJ-45 LAN port. Connect an Ethernet cable to the LAN port on the ICA-310 and connect the other side of the Ethernet cable to a hub/switch or PoE device.
3. Connect RS485 D+ and D- interface (if you need to control P/T external scanner).
4. Connect the bundled power adapter to camera and plug-in this adapter into power outlet. OR , connect your ICA-310 to a PoE device.
5. Connect Video BNC connector to a local TV monitor or DVR if necessary.
6. Done.

2.4 Initial Utility Installation

This chapter shows how to quick set up your ICA-310. The ICA-310 is with the default settings. However to help you find the networked camera quickly the windows utility-IP Wizard can search the cameras in the network that shall help you to configure some basic setting before you started advanced management and monitoring.

1. Insert the bundled CD into the CD-ROM drive to launch the autorun program. Once completed, a welcome menu screen will appear. Please click your IP camera model name to next page.

2. Click the “IP Wizard” hyperlink; you will see the InstallShield Wizard dialog box as below.

   NOTE: If the welcome screen does not appear, click “Start” at the taskbar. Then, select “Run” and type “D:\Utility\IPWizard\setup.exe”, assume D is your CD-ROM drive.


InstallShield Wizard
IPWizard Setup is preparing the InstallShield Wizard which will guide you through the program setup process. Please wait.
Cancel

3. The “Welcome to the InstallShield Wizard for IP Wizard” will display on the screen and click “Next” to continue.

IPWizard - InstallShield Wizard
Welcome to the InstallShield Wizard for IPWizard
The InstallShield(R) Wizard will install IPWizard on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel

4. Please click “Next” to install with original settings, or you may click “Change…” button to modify the install folder then press “Next” to continue.

5. Please click “Install” to start the installation.



6. Please click “Finish” to complete the installation

IPWizard - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed IPWizard. Click Finish to exit the wizard.
< Back
Finish
Cancel

7. Please double-click the utility icon

on the desktop then you will see the ICA-310 utility.

2.5 IP Wizard

When you installed the ICA-310 on a LAN environment, you may execute IP Wizard to discover ICA-310's IP address and set up related parameters in the ICA-310.

Search Button:

When click Search button, a searching window will pop up. IP Wizard is starting to search ICA-310 on the LAN. The message "No Network Devices Is Found" will appear on this window if IP Wizard cannot find any camera on the LAN. Otherwise, existed cameras will be listed. If total quantity is over, please move the cursor to Information Box. Click on the left button of the mouse and the Information Box of the Listing Window will roll upward automatically; on the contrary, move the cursor to the Information Box on the top of Listing Window and click on the left button of the mouse and Listing Window will roll downward.

Wizard Button:

When IP Wizard finds your camera, **Wizard** button will become available. Please select the device you would like to configure in the Information Box. The device will turn into yellow which means this device is selected; please press "**Wizard**" button. Or you could double click the mouse left key on the selected camera. Relative settings will be carried out. Details of Install Wizard will be specified as Section 2.6.



About Button:

When click "About" button, you will see the version information of IP Wizard shown in the pop-up dialog box.

Exit Button:

Click "**Exit**" button will close the IP Wizard Program.

2.6 Configure With IP Wizard

After pressing Installation Wizard, please key in Username and Password of the device when login dialog box appears on the screen. You can login the setup page if authorized name and password is correct. Default **username/password** for machine login: **admin**/<no password>



Wizard Page 1: Username and Password

This page is about the change of the authorized user name and password of the selected device. If you don't want to change them, please click "Next" to move to the next page. Press "Exit" button if you don't want to set up right now. If you want to change authorized name or password, you have to check the box in front of **ID** or **New Password**. Authorized Username should contain at least 5~20 characters and New Password should contain at least 4~8 characters.



Wizard Page 2: LAN Setting

This page is about the select of Static IP or DHCP IP.



LAN	You can configure this ICA-310 to obtain its address automatically or manually assign. If there is a DHCP server in your network environment and you select "**DHCP IP**", ICA-310 can automatically obtain an IP address. If you don't have DHCP server or you want to use fixed IP address, please select "**Static IP**" and fill in the following fields with proper parameters.
IP Address	IP address is a unique number for identifies this device on the WAN or LAN. These numbers are usually shown in groups separated by periods, for example: 192.168.0.200
Subnet Mask	Subnets allow network traffic between hosts to be separated based on the network's configuration. In IP networking, traffic takes the form of packets. IP subnets advance network security and performance to some level by organizing hosts into logical groups. Subnet masks contain four bytes and usually appear in the same "dotted decimal" data. For example, a very common subnet mask in its binary demonstration 11111111 11111111 11111111 00000000 will usually be shown in the corresponding, more readable form as 255.255.255.0.
Def. Gateway	A gateway is a piece of software or hardware that passes information between networks. You'll see this term most often when you either log in to an Internet site or when you're transient email between different servers.
DNS1	When you send email or position a browser to an Internet domain such as xxxxx.com, the domain name system translates the names into IP addresses. The term refers to two things: the conventions for naming hosts and the way the names are control across the Internet.
DNS2	The same function as DNS1. It is optional, not necessary

Note: If no IP address is assigned after 30 seconds, the ICA-310 will work with its default IP address **192.168.0.20**. User may now open your web browser, and key in http://192.168.0.20 in the address bar of your web browser to logon ICA-310's web configuration page.

Wizard Page 3: Confirmation

This page shows the new configurations. If it is correct, please press "Submit" icon and the setting information will be save to your ICA-310. Click on "Exit" to close this window.



2.7 UPnP Function

NOTE: Windows 2000 does not support UPnP feature.

2.7.1 Windows XP

UPnP™ is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled device. If the operating system, Windows XP, of your PC is UPnP enabled, the device will be very easy to configure. Use the following steps to enable UPnP settings only if your operating system of PC is running Windows XP.

Go to **Start > Settings**, and Click **Control Panel**



The “Control Panel” will display on the screen and double click **Add or Remove Programs** to continue



The “Add or Remove Programs” will display on the screen and click **Add/Remove Widows Components** to continue.


Add or Remove Programs
Change or Remove Programs
Add New Programs
Add/Remove Windows Components
Set Program Access and Defaults
Currently installed programs:
Sort by: Name
DameWare NT Utilities
Click here for support information.
Size 15.22MB
Used occasionally
Last Used On 11/18/2003
To change this program or remove it from your computer, click Change or Remove.
Change
Remove
Internet Explorer Q828750
IP surveillance
Size 3.30MB
Outlook Express Update Q330994
Windows Media Player Hotfix [See wm828026 for more information]
Size 0.13MB
Windows XP Hotfix - KB821557
Windows XP Hotfix - KB823182
Windows XP Hotfix - KB823559
Windows XP Hotfix - KB824105
Windows XP Hotfix - KB824141
Windows XP Hotfix - KB824146
Windows XP Hotfix - KB825119
Windows XP Hotfix - KB828035
Windows XP Hotfix (SP2) [See Q329048 for more information]
Windows XP Hotfix (SP2) [See Q329115 for more information]
Windows XP Hotfix (SP2) [See Q329390 for more information]

The following screen will appear, select **Networking Services** and click **Details** to continue


Windows Components Wizard
Windows Components
You can add or remove components of Windows XP.
To add or remove a component, click the checkbox. A shaded box means that only part of the component will be installed. To see what's included in a component, click Details.
Components:
Message Queuing 0.0 MB
MSN Explorer 13.2 MB
Networking Services 0.3 MB
Other Network File and Print Services 0.0 MB
Outlook Express 0.0 MB
Description: Contains a variety of specialized, network-related services and protocols.
Total disk space required: 54.7 MB
Space available on disk: 1926.8 MB
Details...
< Back
Next >
Cancel

The “Networking Services” will display on the screen, select **Universal Plug and Play** and click **OK** to continue.


Networking Services
To add or remove a component, click the check box. A shaded box means that only part of the component will be installed. To see what's included in a component, click Details.
Subcomponents of Networking Services:
Internet Gateway Device Discovery and Control Client 0.0 MB
RIP Listener 0.0 MB
0.0 MB
Universal Plug and Play 0.2 MB
Description: Allows you to find and control Internet connection sharing hardware and software that uses Universal Plug and Play.
Total disk space required: 54.7 MB
Space available on disk: 1926.8 MB
Details...
OK
Cancel

Please click **Next** to continue


Windows Components Wizard
Windows Components
You can add or remove components of Windows XP.
To add or remove a component, click the checkbox. A shaded box means that only part of the component will be installed. To see what's included in a component, click Details.
Components:
Message Queuing 0.0 MB
MSN Explorer 13.2 MB
Networking Services 0.3 MB
Other Network File and Print Services 0.0 MB
Outlook Express 0.0 MB
Description: Contains a variety of specialized, network-related services and protocols.
Total disk space required: 54.7 MB
Space available on disk: 1926.8 MB
Details...
< Back
Next >
Cancel

The program will start installing the UPnP automatically. You will see the below pop-up screen, please wait while Setup configures the components.


Windows Components Wizard
Configuring Components
Setup is making the configuration changes you requested.
Please wait while Setup configures the components. This may take several minutes, depending on the components selected.
Status: Completing configuration of Internet Information Services (IIS)...
< Back
Next >

Please click **Finish** to complete the UPnP installation

Windows Components Wizard
Completing the Windows Components Wizard
You have successfully completed the Windows Components Wizard.
To close this wizard, click Finish.
< Back
Finish

Double-click **My Network Places** on the desktop, the “My Network Places” will display on the screen and double-click the UPnP icon with ICA-310 to view your device in an internet browser.



2.7.2 Windows Vista

UPnP™ is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled device. If the operating system, Windows Vista, of your PC is UPnP enabled, the device will be very easy to configure. Use the following steps to enable UPnP settings only if your operating system of PC is running Windows Vista.

Go to **Start > Control Panel > Network and Internet > Network and Sharing Center,** and turn on **Network Discovery**.



Double-click **My Network Places** on the desktop, the “My Network Places” will display on the screen and double-click the UPnP icon with ICA-310 to view your device in an internet browser.



2.8 Setup ActiveX to use the ICA-310

The ICA-310 web pages communicate with the ICA-310 using an ActiveX control. The ActiveX control must be downloaded from the ICA-310 and installed on your PC. Your Internet Explorer security settings must allow for the web page to work correctly. To use the ICA-310, user must setup his IE browser as follows:

2.8.1 Internet Explorer 6 for Windows XP

From your IE browse ➔ "Tools" ➔ "Internet Options…" ➔ "Security" ➔"Custom Level…", please setup your "Settings" as follow.

Set the first 3 items

- *Download the signed ActiveX controls*
- *Download the unsigned ActiveX controls*
- *Initialize and script the ActiveX controls not masked as safe to Prompt*



By now, you have finished your entire PC configuration for ICA-310.

2.8.2 Internet Explorer 7 for Windows XP

From your IE browse ➔ ”Tools” ➔ ”Internet Options…” ➔ ”Security” ➔”Custom Level…”, please setup your “Settings” as follow.

Set the first 3 items

- *Allow previously unused ActiveX control to run…*
- *Allows Script lets*
- *Automatic prompting for ActiveX controls*



By now, you have finished your entire PC configuration for ICA-310.

2.8.3 Internet Explorer 7 for Windows Vista

From your IE browse ➔ ”Tools” ➔ ”Internet Options…” ➔ ”Security” ➔ ”Internet” ➔”Custom Level…”, please setup your “Settings” as follow.

- *Enable “Automatic prompting for ActiveX controls”*
- *Prompt “Initialize and script active controls not marked….”*





From your IE browse ➔ ”Tools” ➔ ”Internet Options…” ➔ ”Security” ➔ ”Trusted Sites” ➔”Custom Level…”, please setup your “Settings” as follow.

- *Enable “Automatic prompting for ActiveX controls”*
- *Prompt “Initialize and script active controls not marked….”*





By now, you have finished your entire PC configuration for ICA-310.

3. Web-based Management

This chapter provides setup details of the ICA-310's Web-based Interface.

3.1 Introduction

The ICA-310 can be configured with your Web Browser. Before configure, please make sure your PC is under the same IP segment with ICA-310.

3.2 Connecting to ICA-310

- Use the following procedure to establish a connection from your PC to the ICA-310.
- Once connected, you can add the ICA-310 to your Browser's Favorites or Bookmarks.

Start the web browser on the computer and type the IP address of the ICA-310. The Default IP: " http://192.168.0.20 "

The login window of ICA-310 will appear, Default login **username/password** is :

admin/ <no password>

;

NOTE: If the User name and Password have been changed with IP Wizard, please enter the new User name and Password here.

Web browser may display the “Security Warming” window, select “Yes” to install and run the ActiveX control into your PC.


http://192.168.0.20/ - Microsoft Internet Explorer
Security Warning
Do you want to install and run "http://192.168.0.20/LT/WinWebPush.cab"?
The publisher cannot be determined due to the problems below:
Authenticode signature not found.
Yes
No
More Info

After the ActiveX control was installed and run, the first image will be displayed.



NOTE: If you log in the ICA-310 as an ordinary user, setting function will be not available. If you log in the ICA-310 as the administrator, you can perform all the settings provided within the device.

3.3 Live View

Start-up screen will be as follow no matter an ordinary users or an administrator.



Monitor Image Section	The image shot by the ICA-310 is shown here. The date and time are displayed at the top of the window.
Video Profile	The ICA-310 support multi-profile for both MEPG-4 and M-JPEG simultaneously. User can chose the proper and/or preferred profile here.
ActiveX Control	The plug-in ActiveX control supports a lot of functions by clicking the left mouse button. Note that this feature only supports on the ActiveX control within Microsoft® Internet Explorer.
De-Interlace	The device also supports de-interlace function inside ActiveX. User can chose to enable or disable this function by toggling the icon below. : Disable de-interlace function. : Enable de-interlace function.

Setting Menu	This function is detail setting for ICA-310 that only available for user logged into ICA-310 as administrator.

Item	**Action**
Network	Configure Network settings such as DHCP, DDNS, 3GPP, PPPoE and UPnP
Camera	Adjust camera parameters
System	Configure system information, date & time, maintenance, and view system log file.
Video	Configure bit rate and frame rate of video profiles
User	Setup user name, password and login privilege
E-Mail	Setup E-Mail configuration
Object Detection	Setup Object detection
Event Server	This device is a client site and configure information to upload images to server
Event Schedule	Configure the schedule while event triggered

Streaming Protocol	User can select proper streaming protocol according to networking environment.
Language	The device could provide multiple languages to meet customer's requirement.
Video Information	Display video information including video format, resolution, frame rate and bit rate.

PTZ Control	Click to display the following control panel:



Hide PTZ Control	Click the icon will hide the PTZ control function.
Camera Direction	Control camera up/down/left/right and home position.
Camera Speed	Choose the speed of Pan and Tilt.
Preset	Add/Update the preset positions or go to one of these positions.
Tour	Select one of the camera tours. Camera tour is comprised by series of preset locations.
Go Tour	Execute the selected camera tour.
Auto Pan	Execute the auto pan of camera. While auto pan is running, the camera will swing the camera automatically. Note that the speed of auto pan is fixed and cannot be adjustable.

3.4 ActiveX Control

The plug-in ActiveX control supports a lot of functions by clicking the left mouse button. Note that this feature only supports on the ActiveX control within Microsoft® Internet Explorer.

On the ActiveX control icon, click the LeftMouseButton, then a menu pop-up. This menu provides features that are unique to the ActiveX control. These features include:

- *"Digital Zoom",*
- *"Record",*
- *"Snapshot",*
- *"Statistics",*
- *"About"*

3.4.1 Digital Zoom

Click **Digital Zoom** to active this function as above. User can drag or scale the box over the video to adjust zoom ratio and position.



3.4.2 Record

Click **Record** to activate this function. Press **Record** button to start recording. The video file is saved as ASF format into your local PC. While you want to stop it, press **Stop** to stop recording. Select **Browser**, the pop-up window to select the save path and file name prefix, select **OK** to continue.

After stop recording, list the files, this file is named as Video_yyyymmddhhmmss.asf

The ASF files can be display by the standard Windows Media Player, but it needs the DixectX 9.0 or later version to be installed.

NOTE: Default save path is “C:\Documents and Settings\All user\Desktop



3.4.3 Snapshot

Click **Snapshot** to activate this function. Press **Snapshot** button to take a picture. The image file is saved as JPEG format into your local PC. Select **Browser**, the pop-up window to select the save path and file name prefix, select **OK** to continue.

If you like to retrieve the saved image, select the file to display the saved image by using any one of graph editing tools.

NOTE: Default save path is “C:\Documents and Settings\All user\Desktop



3.4.4 Statistics

Click **Statistics** to activate this function. A window will be popup to show the statistics information of the streaming status. **Note** that this information is the statistics between the device and your local PC.



3.4.5 About

Click **About** to show the ActiveX information

3.5 Network

Use this menu to configure the network to connect the device and the clients.

3.5.1 Network

This section provides the menu of connecting the device through Ethernet cable.



MAC Address	Display the Ethernet MAC address of the device. Note that user cannot change it.
Obtain an IP address automatically (DHCP)	DHCP: Stands for Dynamic Host Configuration Protocol. Enable this checked box when a DHCP server is installed on the network to issue IP address assignment. With this setting, the IP address is assigned automatically. If this device cannot get an IP address within limited tries, the device will assign a default IP address, 192.168.0.20, by itself as the default IP address.
IP address, Subnet mask, Gateway, 1st DNS, 2nd DNS server	If you do not select Obtain an IP address automatically, then you need to enter these network parameters by yourself.
IP Address	This address is a unique numbers that identifies a computer or device on the WAN or LAN. These numbers are usually shown in groups separated by periods, for example: 192.168.0.200
Subnet Mask	Subnets allow network traffic between hosts to be separated based on the network's configuration. In IP networking, traffic takes the form of packets. IP subnets advance network security and performance to some level by organizing hosts into logical groups. Subnet masks contain four bytes and usually appear in the same "dotted decimal" data. For example, a very common subnet mask in its binary demonstration 11111111 11111111

	11111111 00000000 will usually be shown in the corresponding, more readable form as 255.255.255.0.
Gateway	A gateway is a piece of software or hardware that passes information between networks. You'll see this term most often when you either log in to an Internet site or when you're transient email between different servers.
Primary DNS	When you send email or position a browser to an Internet domain such as xxxxx.com, the domain name system translates the names into IP addresses. The term refers to two things: the conventions for naming hosts and the way the names are control across the Internet.
Secondary DNS	The same function as DNS1. It is option not necessary
Note: need to reboot the device to take this setting effect.	
HTTP Port	The device supports two HTTP ports. The first one is default port 80 and this port is fixed. This port is very useful for Intranet usage. The second HTTP port is changeable. Users could assign the second port number of http protocol, and the WAN users should follow the port number to login. If the http port is not assigned as 80, users have to add the port number in back of IP address. For example: http://192.168.0.20:80. If multiple devices are installed on the LAN and also required to be accessed from the WAN, then the **HTTP Port** can be assigned as the virtual server port mapping to support multiple devices.
When the configuration is finish, please click “OK” to save and enable the setting.	

3.5.2 DDNS server

DDNS: Stands for Dynamic Domain Name Server

The device supports DDNS. If your device is connected to xDSL directly, you might need this feature. However, if your device is behind a NAT router, you will not need to enable this feature. Because DDNS allows the device to use an easier way to remember naming format rather than an IP address. The name of the domain is like the name of a person, and the IP address is like his phone number. On the Internet we have IP numbers for each host (computer, server, router, and so on), and we replace these IP numbers to easy remember names, which are organized into the domain name. As to xDSL environment, most of the users will use dynamic IP addresses. If users want to set up a web or a FTP server, then the Dynamic Domain Name Server is necessary. For more DDNS configuration, please consult your dealer.

Your Internet Service Provider (ISP) provides you at least one IP address which you use to connect to the Internet. The address you get may be static, meaning it never changes, or dynamic, meaning it’s likely to change periodically. Just how often it changes, depends on your ISP. A dynamic IP address complicates remote access since you may not know what your current WAN IP address is when you want to access your network over the Internet. The solution to the dynamic IP address problem comes in the form of a dynamic DNS service.

The Internet uses DNS servers to lookup domain names and translates them into IP addresses. Domain names are just easy to remember aliases for IP addresses. A dynamic DNS service is unique because it provides a means of updating your IP address so that your listing will remain current when your IP address changes. There are several excellent DDNS services available on the Internet and best of all they're free to use. One such service you can use is www.DynDNS.org. You'll need to register with the service and set up the domain name of your choice to begin using it. Please refer to the home page of the service for detailed instructions or refer to Appendix D for more information.



DDNS	To enable or disable the DDNS service here.
Server Name	Choose the built-in DDNS server.
DDNS Host	The domain name is applied of this device.
User Name	The user name is used to log into DDNS.
Password	The password is used to log into DDNS.

3.5.3 PPPoE

PPPoE: Stands for Point to Point Protocol over Ethernet

A standard builds on Ethernet and Point-to-Point network protocol. It allows ICA-310 connect to Internet with xDSL or cable connection; it can dial up your ISP and get a dynamic IP address. For more PPPoE and Internet configuration, please consult your ISP.

It can directly connect to the xDSL, however, it should be setup on a LAN environment to program the PPPoE information first, and then connect to the xDSL modem. Power on again, then the device will dial on to the ISP connect to the WAN through the xDSL modem.

The procedures are

- Connect to a LAN by DHCP or Fixed IP
- Access the device, enter **Setting ➔ Network ➔ PPPoE** as below



PPPoE	To enable or disable the PPPoE service here.
User Name	Type the user name for the PPPoE service which is provided by ISP.
Password	Type the password for the PPPoE service which is provided by ISP.
IP Address, Subnet Mask, and Gateway	Shows the IP information got from PPPoE server site.
Status	Shows the Status of PPPoE connection.

3.5.4 Streaming

RTSP is a streaming control protocol, and a starting point for negotiating transports such as RTP, multicast and Unicast, and for negotiating codecs. RTSP can be considered a "remote control" for controlling the media stream delivered by a media server. RTSP servers typically use RTP as the protocol for the actual transport of audio/video data.



RTSP Port	Choose the RTSP port. The RTSP protocol allows a connecting client to start a video stream. Enter the RTSP port number to use. The default value is 554.
RTP Port	Specify the range of transmission port number of video stream. The default range is 50000 to 50999. User can specify a number between 1024 and 65535.

To use the 3GPP function, in addition to previous section, you might need more information or configuration to make this function work.

NOTE: To use the 3GPP function, it strongly recommends installing the Networked Device with a public and fixed IP address without any firewall protection.

RTSP Port	Port 554 is the default for RTSP service. However, sometimes, some service providers change this port number for some reasons. If so, user needs to change this port accordingly.

Dialing procedure

1. Choose a verified player (PacketVideo or Realplayer currently)
2. Use the following URL to access: **rtsp://host/mpeg4/media.3gp**

Where host is the host name or IP address of the camera.

Compatible 3G mobile phone	Please contact your dealer to get the approved list of compatible 3G phone.

3.5.5 UPnP

UPnP is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled Network Camera. If your operating system is UPnP enabled, the device will automatically be detected and a new icon will be added to “My Network Places.” If you do not want to use the UPnP functionality, it can be disabled

In addition, this device also provides UPnP IGD function for NAT traversal easily. Use NAT traversal when your device is located on an intranet (LAN) and you wish to make it available from the other (WAN) side of a NAT router. With NAT traversal properly configured, all HTTP traffic to an external HTTP port in the NAT router will be forwarded to the device.



UPnP	To enable or disable the UPnP service here.
Friendly Name	Shows the friendly name of this device here.
UPnP NAT Traversal	When enabled, the device will attempt to configure port mapping in a NAT router on your network, using UPnP™. Note that UPnP™ must be enabled in the NAT router first.
Port Range	The port range will open in NAT router.
External IP Address	Show the IP address and port for WAN access through Internet. If NAT traversal is configured successfully, user can use this IP address and port to access this device.

3.5.6 IP Filter

You can enter different user's IP address which are allowing enter or denying by the device.



IP Filter	To enable or disable the IP filter function here.
IP Filter Policy	Choose the filter policy where is denying or allowing.

3.5.7 IP Notification

In case the IP address is changed, system is able to send out an email to alert someone if the function is enabled.



SMTP Notification (e-mail)	If enable this function, then the "**Send to**" and "**Subject**" field need to be filled.
Send To	Type the receiver's e-mail address. This address is used for reply mail.
Subject	Type the subject/title of the E-mail.
TCP Notification	If enable this function, then the "**TCP Server**", "**TCP Port**", and "**Message**" fields need to be filled.
TCP Server	Type the server name or the IP address of the TCP server.
TCP Port	Set port number of TCP server.
Message	The message will be sent to FTP server.
HTTP Notification	If enable this function, then the fields below need to be filled.
URL	Type the server name or the IP address of the HTTP server.
HTTP Login Name	Type the user name for the HTTP server.

HTTP Login Password	Type the password for the HTTP server.
Proxy Address	Type the server name or the IP address of the HTTP Proxy.
Proxy Port	Set port number of Proxy.
Proxy Login Name	Type the user name for the HTTP Proxy.
Proxy Login Password	Type the password for the HTTP Proxy.
Custom Parameter	User can set specific parameters to HTTP server.
Message	The message will be sent to HTTP server.

3.6 Camera

Use this menu to set the function of the camera of ICA-310

3.6.1 Picture



Brightness	Large value will brighten camera.
Sharpness	Large value will sharpen camera.
Contrast	Large value will contrast camera heavily.
Local Video Output	Check this item if a TV or video monitor has been connected to video output of the Network Camera. Un-check it if not any device has been connected. Otherwise, the image will be too brightness

3.6.2 PTZ Setting



PTZ Protocol Type	The Network Camera is connected to built-in ICA-310 and controls this device thru RS485 bus.
Baud Rate	This is the communication speed between network module and ICA-310. Note that please DO NOT changes the default value except on special purpose. If so, user needs to check and set value properly for both sides
Camera ID	This is the camera ID set in speed dome camera. Note that please DO NOT changes the default value except on special purpose. If so, user needs to check and set value properly for both sides

3.6.3 Preset Setting

This page provides the edit tool to modify or delete the “Preset Setting” item by item.



3.6.4 Tour Setting

Up to 64 positions can be preset, and the camera can be programming to move to the preset position sequentially.



Tour Name	The group name of the sequence of camera tour. The maximum number of camera tour is 16.

Running	Enable or disable this camera tour.
Preset	Set the sequence of the tour. Maximum 16 points can be assigned. The selected preset position is added in the Sequence list from 1 to 16.
Wait Time	Type a period of time during which the camera is to stay at each preset point, between 0 to 36000 seconds.

To use the camera tour function, user must preset some camera positions first. The maximum number of preset points is 64.

3.7 System

Use this menu to perform the principal settings of ICA-310.

3.7.1 System


System
Date & Time
Maintenance
Device Title
ICA-310
(0 ~ 30 Digits)
Software Version
3.0.2.2033
Log
Reload
Nov 8 20:15:00 ICA-310 syslog.info syslogd started: BusyBox v1.01 (2008.05.09-08:44
Nov 8 20:15:00 ICA-310 user.notice kernel: klogd started: BusyBox v1.01 (2008.05.09
Nov 8 20:15:00 ICA-310 user.emerg kernel: Linux version 2.4.19-pl1029 (richard@loca
Nov 8 20:15:00 ICA-310 user.emerg kernel: CPU: Faraday FA526id(wb) revision 1
Nov 8 20:15:00 ICA-310 user.emerg kernel: ICache:16KB enabled, DCache:16KB enabled,
Nov 8 20:15:00 ICA-310 user.emerg kernel: Machine: Prolific ARM9v4 - PL1029
Nov 8 20:15:00 ICA-310 user.emerg kernel: Prolific arm arch version 1.0.12
Nov 8 20:15:00 ICA-310 user.emerg kernel: On node 0 totalpages: 8192
Nov 8 20:15:00 ICA-310 user.emerg kernel: zone(0): 8192 pages.
Nov 8 20:15:00 ICA-310 user.emerg kernel: zone(1): 0 pages.
Nov 8 20:15:00 ICA-310 user.emerg kernel: zone(2): 0 pages.
Nov 8 20:15:00 ICA-310 user.emerg kernel: Kernel command line: root=/dev/norblock/c
Nov 8 20:15:00 ICA-310 user.debug kernel: Relocating machine vectors to 0xffff0000

Device Title	You can enter the name of this unit here. It's very useful to identify the specific device from multiple units.
Software Version	This information shows the software version in the device.
Log	User can check the system log information of the device, including the Main Info, Appended Info, Operator IP, and so on …

3.7.2 Date & Time

You can setup the time setting of ICA-310, make it synchronized with PC or remote NTP server. Also, you may select the correct time zone of your country.



Server Date & Time	Displays the date and time of the device	
PC Time	Displays the date and time of the connected PC	
Adjust	**Manual setting:**	Click this option to set time and date manually
	Synchronize with NTP:	Click this option if you want to synchronize the device's date and time with those of time server called NTP server (Network Time Protocol)
	Synchronize with PC:	Click this option to enable time synchronization with PC time
NTP Server Name	Type the host name or IP address or domain name of the NTP server.	
NTP Sync. Interval	Select an interval between 1 and 23 hours at which you want to adjust the device's time referring to NTP server	
Time Zone	Set the time difference from Greenwich Mean Time in the area where the device is installed.	
Daylight Saving	Check this item to enable daylight saving adjustment.	
Daylight Saving Start Time	Sets up the date and time of daylight saving start time.	

Daylight Saving Stop Time	Sets up the date and time of daylight saving stop time.
Daylight Saving Offset	Sets up the date of daylight saving offset.

3.7.3 Maintenance



Hard Factory Default (Include the network setting)	Recall the device hard factory default settings. Note that click this button will reset all device's parameters to the factory settings (including the IP address).
Factory Default (Except the network setting)	The unit is restarted and most current settings are reset to factory default values. This action will not reset the network setting.
Backup Setting	To take a backup of all of the parameters, click this button. If necessary, it will then be possible to return to the previous settings, if settings are changed and there is unexpected behavior.
Restore Setting	Click the "Browse" button to locate the saved backup file and then click the "Restore Setting" button. The settings will be restored to the previous configuration.
Firmware Upgrade	The device supports new firmware upgrade. 1. Close all other application programs which are not necessary for firmware update. 2. Make sure that only you access this device at this moment

	3. Disable Motion Detection function. 4. Select "**Firmware name**" 5. Select the Firmware binary file. (**Note** that it must make sure that the Firmware only applies to this device, once update, it will be burned into FLASH ROM of system.) 6. Once the firmware file was selected, select "Upgrade". 7. The upgrade progress information will be displayed on the screen. 8. A message will be shown while the firmware upgraded. Once the upgrading process completed, the device will reboot the system automatically. 9. Please wait for 80 seconds, and then you can use IP Wizard to search the device again.

Warning!!! The download firmware procedure cannot be interrupted. If the power and/or network connection are broken during the download procedure, it might possibly cause serious damage to the device.

Please be aware that you should not turn off the power during updating the firmware and wait for finish message.

Furthermore, do not try to upgrade new firmware if it's not necessary.

System Restart	The device is restarted without changing any of the settings.

3.8 Video

This device provides more video profiles as below to support different request to each client simultaneously. Each user can choose his preferred video profile as his request independently.

3.8.1 Common



Text Overlay Setting	There are some important information can be embedded into image, including date, time, and/or text.

3.8.2 MPEG4/VGA



Video Type	It's MPEG4 mode in this profile
Resolution	It's VGA mode (640x480) in this profile
Bit rate Control	Defines the rate control method of this profile. There are two options: Constant Bit Rate (CBR) or Variable Bit Rate (VBR). For CBR, the video bit rate is between 384kbps and 4096kbps. User can set the desired bit rate to match the limitation of bandwidth. For VBR, user should choose the quality level to set the video quality rather than bit rate. The quality level is between 1 and 100. The higher value is the better quality.
Max Frame Rate	Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max frame rate versus video quality under the limited bandwidth.

3.8.3 MPEG4/QVGA



Video Type	It's MPEG4 mode in this profile.
Resolution	It's QVGA mode (320x240) in this profile.
Bit rate Control	Defines the rate control method of this profile. There are two options: Constant Bit Rate (CBR) or Variable Bit Rate (VBR). For CBR, the video bit rate is between 128kbps and 1024kbps. User can set the desired bit rate to match the limitation of bandwidth. For VBR, user should choose the quality level to set the video quality rather than bit rate. The quality level is between 1 and 100. The higher value is the better quality.
Max Frame Rate	Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max frame rate versus video quality under the limited bandwidth

3.8.4 MPEG4/QQVGA



Video Type	It's MPEG4 mode in this profile.
Resolution	It's QQVGA mode (160x120) in this profile.
Bit rate Control	Defines the rate control method of this profile. There are two options: Constant Bit Rate (CBR) or Variable Bit Rate (VBR). For CBR, the video bit rate is between 24kbps and 320kbps. User can set the desired bit rate to match the limitation of bandwidth. For VBR, user should choose the quality level to set the video quality rather than bit rate. The quality level is between 1 and 100. The higher value is the better quality.
Max Frame Rate	Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max frame rate versus video quality under the limited bandwidth.

3.8.5 VIDEO/JPEG



Video Type	It's JPEG mode in this profile.
Resolution	User can select VGA, QVGA, or QQVGA mode as the resolution of this JPEG profile.
Rate Control	The quality level is between 1 and 100. The higher value is the better quality.
Max Frame Rate	Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max frame rate versus video quality under the limited bandwidth.

3.9 User

Use this menu to set the user names and password of the Administrator and up to 10 users, and access right of each user.



Viewer Login	**Anonymous**	Choose this to enable anonymous user login.
	Only users in database	Choose this to disable anonymous user login.
User Name	Enter the user's new account here which you want.	
Password	Enter the user's new password here.	
Verify Password	Please enter the user's new password here again to confirm.	
Access Right	Administrator can access every function in this device. However, Viewers only can view the video and access limited function.	
Add, Update, and Remove	Manage the user's account of viewer user.	

‘

3.10 E-Mail

You may setup SMTP mail parameters for further operation of Event Schedule. That's, if users want to send the alarm message out, it will need to configure parameters here and also add at least one event schedule to enable event triggering.



SMTP Server	Type the SMTP server name or the IP address of the SMTP server.
Test	Send a test mail to mail server to check this account is available or not.
SMTP Port	Set port number of SMTP service.
SMTP Authentication	Select the authentication required when you send an e-mail.
Disable	If no authentication is required when an e-mail is sent.
Enable	If authentication is required when an e-mail is sent.
Authentication User Name	Type the user name for the SMTP server if Authentication is Enable.
Authentication Password	Type the password for the SMTP server if Authentication is Enable.
E-mail To	Type the receiver's e-mail address.
E-mail From	Type the sender's E-mail address. This address is used for reply e-mails.
E-mail Subject	Type the subject/title of the e-mail.

3.11 Object Detection

Use this menu to specify motion detection window 1 to window 4 and set the conditions for detection while observing a captured image.



Add and Del	To add or delete the motion windows. User can specify up to 4 Included and/or Excluded windows to monitor the video captured by this device. By dragging mouse on the image, you can change the position and size of the selected motion window accordingly.
Included or Excluded Window	These windows can be specified as Included or Excluded type.
Included	Windows target specific areas within the whole video image
Excluded	Windows define areas within an Include window that should be ignored (areas outside Include windows are automatically ignored)
Name	Name of the specified motion window.
Object Size	Defines the object size of motion detection. The higher object size will only larger objects trigger motion detection. The lower object size will even small objects trigger motion detection too. Generally speaking, the smaller size will be easier to trigger event.

Sensitivity	Defines the sensitivity value of motion detection. The higher value will be more sensitivity.

3.12 Event Server

Setup FTP/TCP/HTTP server configuration

3.12.1 FTP Server

You may setup FTP parameters for further operation of Event Schedule. That's, if users want to send the alarm message to an FTP server, it will need to configure parameters here and also add at least one event schedule to enable event triggering as SMTP.



Name	User can specify multiple FTP paths as wish. Therefore, user needs to specify a name for each FTP setting.
FTP Server	Type the server name or the IP address of the FTP server.
Test	Check the FTP server whether this account is available or not.
FTP Login Name	Type the user name for the FTP server.
FTP Login Password	Type the password for the FTP server.
FTP Port	Set port number of FTP service.
FTP Path	Set working directory path of FTP server.
FTP Passive Mode	Select passive or active mode connecting to FTP server.

3.12.2 TCP Server

In addition to send video file to FTP server, the device also can send event message to specified TCP server.



Name	User can specify multiple TCP servers as wish. Therefore, user needs to specify a name for each TCP server setting.
TCP Server	Type the server name or the IP address of the TCP server.
TCP Port	Set port number of TCP server.

3.12.3 HTTP Server

The device also can send event message to specified HTTP server.



Name	User can specify multiple HTTP servers as wish. Therefore, user needs to specify a name for each HTTP server setting.
URL	Type the server name or the IP address of the HTTP server.
Test	Check the HTTP server whether it is available or not.
HTTP Login Name	Type the user name for the HTTP server.
HTTP Login Password	Type the password for the HTTP server.
Proxy Address	Type the server name or the IP address of the HTTP Proxy.
Proxy Login Name	Type the user name for the HTTP Proxy.
Proxy Login Password	Type the password for the HTTP Proxy.
Proxy Port:	Set port number of Proxy.

3.13 Event Schedule

3.13.1 Setting

This menu is used to specify the schedule of Events and activate the some actions provided by this device.



Name	Name of the Event or Schedule.
Enable	Enable or disable this Event or Schedule.
Type	Schedule start with Event trigger or Schedule trigger.
Enable Time	Define the feasible time slot.
Trigger by	Select the triggered sources with event trigger.
Action	Define the actions once event triggered.

Example. If you want to upload image from ICA-310 to FTP server periodically. You will need to configure some parameters as below:



NOTE: ICA-310 will send a 15sec recording file to FTP server every min.

3.13.2 Record

You can select which file type you would like to record and set a prefix file name.



Name	Name of the Event or Schedule.
Record File Type	You can select AVI or JPEG format for event recording.
Record File Prefix	You can set a prefix file name for the recording file. The max you can enter 20 digitals.

Appendix A: Reset Factory Default Settings

This button is used to restore the factory default settings. Sometimes restarting the ICA-310 will make the system back to a normal state. If the system still got problem after reset, user can restore the factory default settings and install it again.

Restore the ICA-310:

1. Loosen these two screws.



2. open the top cover
3. Press and hold the button down continuously.



4. Wait at least 10 seconds and release the button. Then the ICA-310 has been restored to factory default settings and reboot again.

Appendix B: PING IP Address

The PING (stands for Packet Internet Groper) command is used to detect whether a specific IP address is accessible by sending a packet to the specific address and waiting for a reply. It's also a very useful tool to confirm ICA-310 installed or if the IP address conflicts with any other devices over the network.

If you want to make sure the IP address of ICA-310, utilize the PING command as follows:

- Start a DOS window.
- Type ping x.x.x.x, where x.x.x.x is the IP address of the ICA-310.

The replies, as illustrated below, will provide an explanation to the problem.


Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
D:\Documents and Settings\Administrator>PING 192.168.0.20
Pinging 192.168.0.20 with 32 bytes of data:
Reply from 192.168.0.20: bytes=32 time=1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Ping statistics for 192.168.0.20:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 0ms, Maximum = 1ms, Average = 0ms
D:\Documents and Settings\Administrator>

If you want to detect any other devices conflicts with the IP address of ICA-310, also can utilize the PING command but you must disconnect the ICA-310 from the network first.

Appendix C: Bandwidth and Video Size Estimation

The frame rate of video transmitted from the ICA-310 depends on connection bandwidth between client and server, video resolution, codec type, and quality setting of server. Here is a guideline to help you roughly estimate the bandwidth requirements for your ICA-310.

The required bandwidth depends on content of video source. The slow motion video will produce smaller bit rate generally and fast motion will produce higher bit rate vice versa. Actual results generated by the ICA-310 may be varying.

Image Resolution	Average range of Data Sizes for JPEG mode	Average bit rate for MPEG4 mode
160 x 120 (QQVGA)	3 ~ 6k byte per frame	64kbps~384kbps @ 30fps
320 x 240 (QVGA)	8 ~ 20k byte per frame	128kbps~768kbps @ 30fps
640 x 480 (VGA)	20 ~ 50K byte per frame	256kbps~4096kbps @ 30fps

Note: Audio streaming also takes bandwidth around 5 kbps to 64kbps. Most xDSL/Cable modem upload speeds may not even reach up to 128 kbps. Thus, you may not be able to receive any video while streaming audio on a 128 kbps or lower connection. Even though the upload speed is more than 128kbps, for optimal video performance, disabling audio streaming will get better video performance.

MJPEG

Resolution	Quality setting	fps setting	Current stream	Current fps
320*240 CIF	Best	5 fps	around 2300Kbps	5 fps
320*240 CIF	Best	15 fps	around 6700Kbps	14.7fps
320*240 CIF	Best	25 fps	around 14300Kbps	28 fps
320*240 CIF	Normal	5 fps	around 400Kbps	4.2 fps
320*240 CIF	Normal	15 fps	around 1200Kbps	13 fps - 14 fps
320*240 CIF	Normal	25 fps	around 1700Kbps	30fps
320*240 CIF	Lowest	5 fps	around 350Kbps	4.2 fps
320*240 CIF	Lowest	15 fps	around 1100Kbps	13 - 14fps
320*240 CIF	Lowest	25 fps	around 2000Kbps	25 fps

MPEG4

Resolution	Stream setting	fps setting	Current stream	Current fps
640*480 VGA	384Kbps	5 fps	373Kbps - 388Kbps	5 fps
640*480 VGA	1024Kbps	5 fps	1024Kbps - 1036Kbps	5 fps
640*480 VGA	2048Kbps	5 fps	around 1800Kbps	5 fps
640*480 VGA	384Kbps	20 fps	around 550Kbps	22 fps
640*480 VGA	1024Kbps	20 fps	around 1400Kbps	20 fps
640*480 VGA	2048Kbps	20 fps	around 2600Kbps	16 - 17fps
320*240 CIF	200Kbps	5 fps	183Kbps - 200Kbps	5 fps
320*240 CIF	1024Kbps	5 fps	760Kbps - 800Kbps	5 fps
320*240 CIF	2048Kbps	5 fps	around 850Kbps	5 fps
320*240 CIF	200Kbps	25 fps	around 240Kbps	28 fps
320*240 CIF	1024Kbps	25 fps	around 1100Kbps	30 fps
320*240 CIF	2048Kbps	25 fps	around 1600Kbps	30 fps
160*120 QCIF	128Kbps	5 fps	117Kbps - 121Kbps	5 fps
160*120 QCIF	1024Kbps	5 fps	around 176Kbps	5 fps
160*120 QCIF	2048Kbps	5 fps	around 220Kbps	5 fps
160*120 QCIF	128Kbps	25 fps	around 155Kbps	30 fps
160*120 QCIF	1024Kbps	25 fps	around 520Kbps	30 fps
160*120 QCIF	2048Kbps	25 fps	around 1000Kbps	30 fps

Appendix D: DDNS Application

1. Preface

If you have a Cable modem or xDSL, this is a great way to host your own Networked Device or other TCP/IP Service. Get your own domain like www.yourname.com, www.yourname.com.tw etc. (Note: This domain must be registered with Internic via registration authorities such as Network Solutions, DirectNIC, Register.com etc). Your domain name's dynamic IP address is automatically tracked by a DDNS server.

Host your own Networked Device and much more no matter what your computer's IP address may be and even if you have dialup, DSL or cable modem internet connection where your computer's IP address changes all the time!! DDNS service supports all top level domain names including but not limited to .com, .net, .org, .to, .uk etc.

2. Ethernet Network Environment

Normally, DDNS service is only necessary for the users that could only obtain dynamic IP addresses. As to the users that could obtain the static valid IP address, they do not usually have to apply the DDNS service. Before we decide if DDNS is necessary for the users, we have to check what kind of Ethernet network environment we have to install our Networked Device on.

(1) Environment of Fixed Valid IP Network

If users could obtain valid IP addresses, they could save the effort to apply DDNS service. Because the IP address in this environment is fixed, users could input the IP address or domain name of demo site directly in the IE browser.

(2) Environment of Dynamic IP Network

If users is under an environment of dynamic IP network (Dial-up xDSL), they have to apply a domain name in advance. Then apply DDNS service. Finally setup the necessary information of DDNS and PPPoE of the Networked Device in order to let the outside administrator be able to access through internet.

3. Application Steps – DDNS & Domain Name

(1). Visit the following web site: http://www.dyndns.org/

(2). Click “Account”

(3). After the columns show up at the left side, click “Create Account”.



(4). Fill the application agreement and necessary information.

a. Username

b. E-mail address and confirmation

c. Password and confirmation

d. Submit all the input information and finish creating an account




Terms of Service
Please read the accepatable use policy (AUP) and accept it prior to creating your account. Also acknowledge that you may only have one (1) free account, and that creation of multiple free accounts will result in the deletion of all of your accounts.
Policy Last Modified: February 6, 2006
1. ACKNOWLEDGMENT AND ACCEPTANCE OF TERMS OF SERVICE
All services provided by Dynamic Network Services, Inc. ("DynDNS") are provided to you (the "Member") under the Terms and Conditions set forth in this Acceptable Use Policy ("AUP") and any other operating rules and policies set forth by DynDNS. The AUP comprises the entire agreement between the Member and DynDNS and supersedes all prior agreements between the parties regarding the subject matter contained herein. BY COMPLETING THE REGISTRATION PROCESS AND CLICKING THE "Accept" BUTTON, YOU ARE INDICATING YOUR AGREEMENT TO BE BOUND BY ALL OF THE TERMS AND CONDITIONS OF THE AUP.
I agree to the AUP:
I will only create one (1) free account:
Click these two options


Next Step
After you click "Create Account", we will create your account and send you an e-mail to the address you provided. Please follow the instructions in that e-mail to confirm your account. You will need to confirm your account within 48 hours or we will automatically delete your account. (This helps prevent unwanted robots on our systems)
Create Account

(5). Check your e-mail mailbox. There will be an e-mail with a title “Your DynDNS Account Information“. Click the hyperlink address to confirm the DDNS service that you just applied. Then DDNS you applied activated.


Click to confirm
Your DynDNS Account 'kkkkk' has been created. You need to visit the confirmation address below within 48 hours to complete the account creation process:
https://www.dyndns.com/account/confirm/oDDGDYN75qTJk_ICGba6vQ
Our basic service offerings are free, but they are supported by our paid services. See http://www.dyndns.com/services/ for a full listing of all of our available services.
If you did not sign up for this account, this will be the only communication you will receive. All non-confirmed accounts are automatically deleted after 48 hours, and no addresses are kept on file. We apologize for any inconvenience this correspondence may have caused, and we assure you that it was only sent at the request of someone visiting our site requesting an account.
Sincerely,
The DynDNS Team


DynDNS
User:
Pass:
Lost Password? - Create Account
About
Services
Account
Support
News
My Account
Create Account
Login
Lost Password?
Account Confirmed
The account kkkkk has been confirmed. You can now login and start using your account.
Be informed of new services, changes to services, and important system maintenance/status notifications by subscribing to our
Once there, you may susbscribe to the Announce list by checking the appropriate box and clicking the "Save Settings" button.

(6). Enter the web page http://www.dyndns.org/ again. Input your username and password that you just applied to login administration interface of DDNS server.

(7). If the correct username and password are input, you can see the following picture at the top-right of the login page.

(8). Click the “Services”.



(9). Click the “ Dynamic DNS ”.


DynDNS
About
Services
Account
Support
News
Services
DNS Services
Domain Registration
SSL Certificates
Mail Services
Network Monitoring
Web Redirection
Account Upgrades
Pricing
My Cart
Services
DynDNS provides a variety of services that help enhance your home or business Internet experience. W
(DNS), high quality domain management, world-class e-mail services, web redirection, and network mor
technical support by e-mail or phone where you speak to a highly trained engineer rather than a call ce
DNS Services
Custom DNS - Our dynamic and static DNS management tool for your own domain
Secondary DNS - Add reliability to your own nameservers
Dynamic DNS - A free DNS service for those with dynamic IP addresses
TLD DNS - DNS for operators of ccTLDs and gTLDs

(10). Click the “Create Hosts”.


Dynamic DNSSM
The free Dynamic DNS service allows you to alias a dynamic IP address to a static hostname in any of the many domains we offer, allowing your computer to be more easily accessed from various locations on th
Internet. We provide this service, for up to five (5) hostnames, free to the Internet community.
Create Hosts
Manage Hosts
The Dynamic DNS service is ideal for a home website, file server, or just to keep a pointer back to your home PC so you can access those important documents while you're at work. Using one of the available third-party update clients you can keep your hostname always pointing to your IP address, no matter how often your ISP changes it. No more fumbling to find that piece of paper where you wrote down your IP address, or e-mailing all your friends every time it changes. Just tell them to visit yourname.dyndns.org instead!

(11). We could create a domain name without any charge at this step. First, we input the host name. (No.1) Then we pick a domain that is easy to remember. Finally (No.2), click the “Add Host” to submit the domain name information. (No.3)



4. Setup the DDNS and PPPoE of Network Device

At last, users have to enter the web page of Networked Device and setup the necessary information of DDNS and PPPoE after the application of DDNS service. Please check the user manual to access the DDNS and PPPoE pages. After saving the modification, restart the device. The external users could browse the Networked Device by the input of their domain name.